

**Assembly instruction
OptiFlow Saab 9-3 T7**

1.



Remove the intake hose between the airpipe and the MAS (mass air sensor)

2.



Remove the EVAP valve from the air box.

3.



Remove the harness connector from the MAS.

4.



Remove the air box (3 attach points)

5.



Remove the MAS from the air box, then remove the rubber packing from the MAS.

6.



Assemble the MAS to the plate, notice the flow direction
In picture 7. Use the original retaining plate with attached
distances and screws.

7.



Assemble the plate to the original holdings.
Connect the harness connector to the MAS.
Attach the EVAP valve.
Assemble the air filter, then the air hose between
The MAS and air pipe

ENJOY!